



SA-61JD

SIDE ARM FIELD MARKER INSTRUCTION SHEET FOR THE JOHN DEERE 1850,1860,1690 &1890 NO-TILL DRILLS

Follow these step-by-step instructions for proper mounting of your SIDE ARM marker(s). Once your marker(s) are mounted, refer to the owners manual for proper adjustment information.

Step #1

The front brackets (stamped N1) in this kit are to be mounted on top of the front 4x6" frame using the 5/8x4x7-1/2" U-bolts enclosed. The N1 bracket should slope up and rearward.

(See Drawings - 61JD)

It is best to have the 2 - N1 brackets separated as far as possible on the SIDE ARM'S main beam (3 x 3" tube). This will give the SIDE ARM greater stability and reduce stress on the mounting brackets.

Step #2

Bolt the rear bracket (stamped N2) sloping up and forward on the rear 4x6 frame using the 5/8x4x7-1/2" U-bolts enclosed. (See Drawings- 61JD)

Step #3

The SIDE ARM can now be fitted into its proper place. Use the 3"x 3" U-bolts enclosed to fasten the marker to the brackets.

On the serial # plate of the SIDE ARM you will find a small letter L (left) or R (right) imprinted. This will help you to determine the proper side of the airdrill for the SIDE ARM Marker(s). Lifting clips are provided on the left marker.

Step #4

Refer to the owners manual for proper adjustment and set-up information.

Note: Cultivators and airdrills even of the same make & models are not always the same. Some on site modifications may be necessary to the mounting brackets and/or implement to insure a proper fit. It will be the responsibility of the installer to make sure that the markers will not interfere with the functions of the implement in anyway.

READ ALL THE INSTALLATION & OPERATION INSTRUCTIONS CAREFULLY!

Hardware Package for SA-61JD

S/D *	
2/4 - Front Brackets - N1	14/28 - 5/8" Nuts
1/2 - Rear Bracket - N2	14/28 - 5/8" Lockwasher
	2/4 - 1/2 x 1-3/4" Carr Blt
4/8 - 5/8x3x4-1/2" U-bolts	2/4 - 1/2" Nuts
3/6 - 5/8x4x7-1/2" U-bolts	2/4 - 1/2" Lockwashers
1 - Can of paint	2/4 - 1/2" Flatwashers
1 - Owners Manual	